


Wiring for Mini-XLR Flying Socket


Sennheiser MKE2 (amplified wiring)

- Pin 1: Screen and blue
- Pin 2: As shown
- Pin 3: Red
- Pin 4: As shown




Sony ECM77

- Pin 1: Screen and clear
- Pin 2: As shown
- Pin 3: Red
- Pin 4: As shown




Sanken COS-11PT

- Pin 1: Screen
- Pin 2: Black
- Pin 3: White
- Pin 4: As shown



Beyer MCE5

- Pin 1: Screen
- Pin 2: Red
- Pin 3: Blue
- Pin 4: As shown



Beyer MCE50

- Pin 1: Screen
- Pin 2: Not connected
- Pin 3: White
- Pin 4: As shown

